



- \* The entire door track and 130SDTDiS are set in above and separate to waterproofing. Therefore waterproofing must be completed first.
- \* The included sub-sil tray must be installed first as the door tracks are installed into tray of the 130SDTDiS.

